

## 3097

### Precleaner 3000

#### Product description

Activates the glass surface for an optimal sealing result with glass sealings. Increases significantly the durability of nano-sealings. Abrasive components remove even the toughest dirt.

#### Advantages

- For precleaning prior to sealing applications
- Cleans glass- and ceramic surfaces

#### Application fields

Abrasive precleaner for nano-sealings.

#### Application

1. Shake well before use.
2. Pour the product onto a cloth and polish in sections in circular motions."
3. Then remove the product residues with water and rub the glass dry.

Note: If the cleaner dries on the surface, it can be diluted with water again. Do not mix with chlorine-based cleaners, since harmful vapors may arise. Do not use on acid-sensitive materials such as marble and other natural stones.



#### Technical Data

Property	Value
Chemical base	Mixture of minerals, organic acids, detergent substances and water
Surfaces	Glass, ceramic
Application temperature	5°C - 25°C
Consumption	Ca. 25 ml / m <sup>2</sup>
pH-value (25°C)	2,5 (1% in water)
Density	1,3 g/ml
Solvent content	< 5 %
Storage stability	24 months
Recommended storage	5°C - 25°C

Find comprehensive advice on health, safety, and environmental protection in the corresponding safety data sheets.

#### Available containers

Container	Volume
PE bottle	35 ml
PE bottle	250 ml

#### Liability notices

This technical information leaflet is the result of careful testing and used to advise our customers. The information contained herein corresponds to our best knowledge. Since proper use does not lie within our influence, however, we can assume liability only for the perfect quality of the products we provided up to the point in time of delivery. We reserve the right to make any changes in this product information due to new knowledge.

KERONA GmbH  
 Zeilbaumweg 15  
 D-74613 Öhringen  
 Phone: +49 7941-9205 4080  
 mail@kerona.de  
 www.kerona.de